







Left-Right

3 heater versions, 1 controller operating them, 2 versions “paired” to thermostat:

WIST ELEGANT (receiving wireless signals from thermostat, plugged into wall outlet)

ECO (receiving wireless signals from thermostat, plugged into wall outlet)

BASIC (directly powered and controlled through thermostat)